


Must be installed at least 15' away from the compressor




Typical Installation for High Speed Compressors

CompressorLynx™ Transmission Unit



To Oil Pressure Sensing Line




To CompressorLynx™ Transmission Unit

Typical Installation for Ajax Compressors

CompressorLynx™ Transmission Unit



Magnetic Switch



Compressor Ignition Coil

To CompressorLynx™ Transmission Unit